
Downtown
Seating



Fabric

Waterproof fiber

Polyurethane foam

Ultra-Flex® membrane

Wood frame

TOOLS

Security glasses

Screwdriver

Pliers

Mallet

Knife


DISASSEMBLY INSTRUCTIONS

1. SOFT MATERIAL

-Use a knife to cut and remove the membrane under the seat.
-Use pliers to remove the staples holding the fabric under the seat and remove the fabric covering the seat.
-Remove the waterproof fiber covering the polyurethane.
-Remove the polyurethane foam covering the wood frame.
-Remove the staples and the Ultra-Flex® membrane.

artopex®

Downtown
Seating



No.	Description	QTY	Materials
1	Back	1	Plywood
2	Side	2	Plywood
3	Bottom frame	1	Plywood
4	Top frame	1	Plywood
5	Front	1	Plywood
6	Top	1	Plywood
7	Side assembly block	4	MDF
8	Side assembly block	2	MDF
9	Side assembly block	2	MDF
10	Seat fasteners	6	Steel
11	Leg	4	Wood
12	Leveller insert	4	Steel
13	Leveller	4	Steel

2. WOOD FRAME

-Use a screwdriver to unscrew the fasteners (10) supporting the top of the seating (6).
-Remove the feet (11), leveller inserts (12) and levellers (13).
-Disassemble the structure using a mallet.

artopex