


AXEL

Système de fixation pour support de télévision /
Attachment system for television mounting bracket



guide d'installation
installation guide

en vigueur le 12 mars 2019
effective March 12th 2019




ATTENTION / WARNING:

Support de télé non inclus
TV mount not included


artopex®

Systeme de fixation pour support de television - *Attachment system for television mounting bracket*

- 1** Assembler les montants de fixation au support de television (non inclus).
Bolt the mounting studs to the television mount (not included).



- 2** Fixer les supports de montants sur les traverses du cadre.
Attach stud brackets to frame rails.




ATTENTION / WARNING:

Pour une installation sur la traverse du haut du cadre, utiliser les supports de montants appropriés.
For installation on top rail of frame, use the appropriate stud brackets.

Système de fixation pour support de télévision - *Attachment system for television mounting bracket*


3

Installer les tuiles adjacentes au supports de montants.
Install tiles adjacent to stud brackets.





4

Positionner l'assemblage des montants et du support de télévision à la hauteur désirée.
Position stud and television mount assembly at the desired height.



5

Fixer l'assemblage des montants aux supports.
Screw stud assembly to the brackets.



Vis / Screw
#10-24 x 2 1/2" (4x)

Rondelle de blocage /
Lock washer #10 (4x)

Écrou / Nut
10-24 (4x)