## Noki Lock - MASTER KEY

## artopex



MASTER KEY

- All locks are programmed with the default code : 1–2–3+0k.
- The Noki lock is functional without the use of keys.

## MASTER KEY (BLACK KEY)

Once inserted, the lock is associated with all master keys of the same serial number.

Master keys with different serial numbers cannot be used on locks already associated with a master key.

Clients can purchase multiple copies of master keys with the same serial number.

## RECOMMENDATION Keep your master key in a safe place

- To reset the code to 1-2-3, insert the key into the lock and press OK.
   A beep will sound.
- The lock is reset to default code: 1-2-3-0k.

Visit **artopex.com** to view the Noki introductory video for more details.