

Metal

Filing cabinet

Product disassembly guide

No.	Description	QTY	Materials
1	Pedestal	1	Steel
2	Fixed drawer	3	Steel
3	Fixed face	3	Steel
4	Mechanical screw	16	Steel
5	Handle	4	Aluminum
6	Card holder	4	PVC
7	White card	4	Cardboard
8	Slide	4	Steel
9	Suspension bar	5	Steel
10	False shelf	1	Steel
11	Rivet	2	Steel
12	Drawer	1	Steel
13	Swing door	1	Steel
14	Swing door right slide	1	Galvanized steel
15	Swing door left slide	1	Galvanized steel
16	Left catch hook	1	Steel
17	Right catch hook	1	Steel
18	Nylon slider	2	Nylon
19	Guide	2	PVC
20	Filing cabinet central lock	1	Steel
21	Safety hook	1	Steel
22	Lock stop	1	Steel
23	Black interlock rod	2	Steel
24	Interlock rod false shelf drawer	1	Steel
25	Leveller	4	Steel

DISASSEMBLY INSTRUCTIONS

1. DRAWERS

- Open the drawers completely (2) and unhook the drawers from the slides (8).
- Remove faces (3-13) aluminum handles (5).
- Remove suspension bars (9).
- Remove the hooks (17), sliders (18) and guides (19).

2. FRAME

- Remove the slides (8 -14).
- Remove the lock and interlock rod (20-21-22-23-24).
- Remove the levellers (25).

